

To purify water in the city

Carolyn Nicolaysen

Use clear plastic PETE water, juice or soda bottles – with 1 in the triangle. Keep a few ready to go by removing the label, washing them with soap and water and rinsing well. Fill with clear water. If your water contains debris or dirt, filter through a clean cloth first. Fill the bottle with clear water. Place the bottle on a piece of metal in the full sun, in 6 hours UVA radiation will kill viruses, bacteria and parasites in the water. If there is no sun then hopefully you are collecting rain water. On a cloudy day you will need to leave the bottle out for at least two full days.

